



MaterialHandling.com

1415 Davis Rd Elgin, IL 60123

Powered by Premier Handling Solutions, Inc.

materialhandling.com | (855) 719-1415 | sales@materialhandling.com

CYHT-1 & CYHT-2



Receiving Instructions

After delivery, remove the packaging from the product. Inspect the product closely to determine whether it sustained damage during transport. If damage is discovered, record a complete description of it on the bill of lading. If the product is undamaged, discard the packaging.

NOTE: The end-user is solely responsible for confirming that product design, use, and maintenance comply with laws, regulations, codes, and mandatory standards applied where the product is used.

Technical Service & Replacement Parts

For answers to questions not addressed in these instructions and to order replacement parts, labels, and accessories, call our Technical Service and Parts Department at (260) 665-7586. The Department can also be contacted online at <https://www.vestil.com/page-parts-request.php>.

Electronic Copies of Instruction Manuals

Additional copies of this instruction manual may be downloaded from <https://www.vestil.com/page-manuals.php>.

Table of Contents

	Page
Signal Words.....	2
Safety Instructions.....	2
Loading Cylinders on the Cart	2
Exploded Views and Bills of Materials.....	3
Record of Satisfactory Condition.....	4
Inspections & Maintenance.....	4
Labeling Diagram.....	4
Limited Warranty.....	5

SIGNAL WORDS

This manual uses SIGNAL WORDS to indicate the likelihood that a particular action will cause personal injuries or property damage. Signal words also specify the level of seriousness of injury if the product is misused in the ways described. The following signal words are used in this manual.



Identifies a hazardous situation which, if not avoided, **WILL** result in **DEATH** or **SERIOUS INJURY**. Use of this signal word is limited to the most extreme situations.



Identifies a hazardous situation which, if not avoided, **COULD** result in **DEATH** or **SERIOUS INJURY**.



Indicates a hazardous situation which, if not avoided, **COULD** result in **MINOR** or **MODERATE** injury.



Identifies practices likely to result in product/property damage, such as operation that might damage the product.

SAFETY INSTRUCTIONS

Vestil strives to identify all foreseeable hazards associated with the use of its products. Material handling is dangerous and no manual can address every conceivable risk. Ultimately, the most effective way to prevent injury is to apply sound judgment whenever using this device.

WARNING Improper or careless use of this product could result in death or serious personal injuries.


- *Read and understand the entire manual before assembling, installing, using or servicing the product.* Read the manual to refresh your understanding of proper use and maintenance procedures.
- DO NOT attempt to resolve any problem(s) with the product unless you are both authorized to do so and certain that it will be safe to use afterwards.
- DO use this product in accordance with the instructions in this manual and consistent with handling cylinders of compressed gasses
- DO NOT modify the product in any way UNLESS you first obtain written approval from Vestil. Unapproved modifications automatically void the LIMITED WARRANTY on p. 5 and might make the product unsafe to use.
- DO NOT exceed the capacity: a) CYHT-1 = 150 pounds (68.1kg); b) CYHT-2 = 250 pounds (113.6kg). Capacity information is provided in product labeling. See Label 1153 in the LABELING DIAGRAM on p. 4.
- Inspect the product according to the instructions in INSPECTIONS & MAINTENANCE on p. 4. DO NOT use the product unless it is in SATISFACTORY CONDITION on p. 4.
- DO NOT use this device UNLESS all product labels are readable and undamaged. See LABELING DIAGRAM.

NOTICE Proper use, maintenance, and storage are essential for this product to function properly.

- Keep the product clean & dry. Lubricate pivot points.

LOADING CYLINDERS ON THE CART


Load the cylinder cart by placing 1 cylinder (CYHT-1) or 2 cylinders (CYHT-2) on the base plate. Move the cylinder(s) against the rear frame element. Wrap the chain around the cylinder(s). Feed the ends of the chain through the holes in the side of the chain plate (CYHT-1) or tool tray (CYHT-2). Pull the chain taut; then press the chain links nearest the holes into the chain slots to lock the chain in place.



EXPLODED VIEW AND BILL OF MATERIALS CYHT-1 (16-006-318)

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	16-514-199	FRAME WELDMENT	1
2	65125	COTTER PIN Z PLATED, 3/16" X 1 1/2"	2
3	16-132-265	10" SHOCK ABSORBING WHEEL	2
4	13-025-037	BLACK HANDLE, 1" ID	2
5	16-145-020	CHAIN #2/0 TWIN LOOP, 45" LG	1


*16-145-020 NOT SHOWN



EXPLODED VIEW AND BILL OF MATERIALS CYHT-2 (16-006-319)

ITEM NO.	PART NO.	DESCRIPTION	QTY.
1	16-514-200	FRAME WELDMENT	1
2	65125	COTTER PIN Z PLATED, 3/16" X 1 1/2"	2
3	33016	FLAT WASHER, LOW CARBON, USS, ZINC PLATED, 5/8"	2
4	16-132-246	16" X 4" FOAM FILLED WHEEL	2
5	16-112-044	AXLE, PIN	1
*6	16-145-021	CHAIN #2/0 TWIN LOOP, 90" LG	1

*16-145-021 NOT SHOWN



RECORD OF SATISFACTORY CONDITION (THE “RECORD”)

After the unit is assembled, make a detailed record of its condition. Include observations about all features: welds, frame elements, fasteners (axle pin, washers, cotter pins, etc.) and wheels. Thoroughly photograph the unit from multiple angles so that all features are recorded. Photograph all labels applied to the product. Describe the location of each label. Collect all photographs and writings in a single file. This file is a record of the cart in satisfactory condition. Compare the results of each inspection to this *RECORD* to determine whether the cart is in satisfactory condition. Do not use the cart unless it is in satisfactory condition

INSPECTIONS AND MAINTENANCE

Compare inspection results to the [RECORD](#). Do not continue to use the cart unless every component is in [SATISFACTORY CONDITION](#). Cosmetic changes, like damaged paint/powder coat do not constitute changes from satisfactory condition. However, touchup paint should be applied to all affected areas as soon as damage occurs. Contact [TECHNICAL SERVICE](#) to order replacement parts. Contact information is provided on the cover page of this manual. DON'T GUESS! If you are unsure whether your cart should be used, contact [TECHNICAL SERVICE](#).

Inspect the following at least once per month:

1. Surfaces – Check all surfaces of the product for dirt or other matter, especially fluids. Clean the surfaces of the stand.
2. Hardware, fasteners – Examine hardware & fasteners (axle pin, washers, cotter pins). Replace damaged/worn hardware.
3. Wheels – Check each wheel and wheel hub for damage such as cracks, significant or uneven wear.
4. Frame – Examine the frame for wear, breaks, corrosion/rusting, metal fatigue, and other forms of damage, e.g. impact damage.
5. Labels – Replace labels that are damaged or not easily readable from a reasonable distance.
6. Overall structure – Examine the whole structure for rusting or metal erosion, rot, thinned regions. In particular, examine the axle pin channel, and ground-contacting elements. If rusting is purely superficial, remove the rust/corrosion. Clean the affected area and apply touchup paint. If rusting, rot, or thinning has weakened the material, contact [TECHNICAL SERVICE](#) for advice.

LABELING DIAGRAM


Label content and locations are subject to change so your product might not be labeled exactly as shown. Compare this diagram to the *RECORD*. If differences exist between the diagram and the *RECORD*, contact [TECHNICAL SERVICE](#). Replace all labels that are damaged, missing, or not easily readable (e.g. faded). To order replacement labels, contact the technical service and parts department online at http://www.vestilmfg.com/parts_info.htm. Alternatively, you may request replacement parts and/or service by calling (260) 665-7586 and asking the operator to connect you to the Parts Department.

Label 658, facing operator

⚠ WARNING	⚠ ADVERTENCIA	⚠ AVERTISSEMENT
Don't operate/move with unstable loads DO NOT LOAD beyond rated capacity DISTRIBUTE LOAD EVENLY DO NOT sit or ride	No use a muera con cargas inestables No cargue mas de la capacidad tasada DISTRIBUYA LA CARGA A NIVEL NO SE SIENTE o vaye en el carro	Nie pas utiliser avec une charge instable NE PAS CHARGER au-delà du débit nominale DISTRIBUER la charge régulièrement NE PAS VOUS ASSÉOIR OU VOUS PROMENER sur le chariot

Label 1153, facing operator

MODEL / MODELO / MODÈLE _____
 WEIGHT / PESO / MASS _____
 CAPACITY / CAPACIDAD / CAPACITÉ _____
 SERIAL / SERIE / SÉRIE _____
 UNITS: 2.2 lb. = 1kg 1" (or 1in.) = 2.54cm 1153





LIMITED WARRANTY

Vestil Manufacturing Corporation ("Vestil") warrants this product to be free of defects in material and workmanship during the warranty period. Our warranty obligation is to provide a replacement for a defective, original part covered by the warranty after we receive a proper request from the Warrantee (you) for warranty service.

Who may request service?

Only a warrantee may request service. You are a warrantee if you purchased the product from Vestil or from an authorized distributor AND Vestil has been fully paid.

Definition of "original part"?

An original part is a part used to make the product as shipped to the Warrantee.

What is a "proper request"?

A request for warranty service is proper if Vestil receives: 1) a photocopy of the Customer Invoice that displays the shipping date; AND 2) a written request for warranty service including your name and phone number. Send requests by one of the following methods:

<u>US Mail</u>	<u>Fax</u>	<u>Email</u>
Vestil Manufacturing Corporation 2999 North Wayne Street, PO Box 507 Angola, IN 46703	(260) 665-1339 <u>Phone</u> (260) 665-7586	info@vestil.com Enter "Warranty service request" in subject field.

In the written request, list the parts believed to be defective and include the address where replacements should be delivered. After Vestil receives your request for warranty service, an authorized representative will contact you to determine whether your claim is covered by the warranty. Before providing warranty service, Vestil will require you to send the entire product, or just the defective part (or parts), to its facility in Angola, IN.

What is covered under the warranty?

The warranty covers defects in the following original, dynamic parts: motors, hydraulic pumps, motor controllers, and cylinders. It also covers defects in original parts that wear under normal usage conditions ("wearing parts"), such as bearings, hoses, wheels, seals, brushes, and batteries.

How long is the warranty period?

The warranty period for original dynamic components is 90 days. For wearing parts, the warranty period is 90 days. Both warranty periods begin on the date Vestil ships the product to the Warrantee. If the product was purchased from an authorized distributor, the periods begin when the distributor ships the product. Vestil may, at its sole discretion, extend a warranty period for products shipped from authorized distributors by up to 30 days to account for shipping time.

If a defective part is covered by the warranty, what will Vestil do to correct the problem?

Vestil will provide an appropriate replacement for any *covered* part. An authorized representative of Vestil will contact you to discuss your claim.

What is not covered by the warranty?

The Warrantee (you) are responsible for paying labor costs and freight costs to return the product to Vestil for warranty service.

Events that automatically void this Limited Warranty.

- Misuse;
- Negligent assembly, installation, operation or repair;
- Installation/use in corrosive environments;
- Inadequate or improper maintenance;
- Damage sustained during shipping;
- Collisions or other accidents that damage the product;
- Unauthorized modifications: Do not modify the product IN ANY WAY without first receiving written authorization from Vestil.

Do any other warranties apply to the product?

Vestil Manufacturing Corp. makes no other express warranties. All implied warranties are disclaimed to the extent allowed by law. Any implied warranty not disclaimed is limited in scope to the terms of this Limited Warranty. Vestil makes no warranty or representation that this product complies with any state or local design, performance, or safety code or standard. Noncompliance with any such code or standard is not a defect in material or workmanship.