




MaterialHandling.com

1415 Davis Rd Elgin, IL 60123

Powered by Premier Handling Solutions, Inc.

materialhandling.com | (855) 719-1415 | sales@materialhandling.com

MTC-PNU-55 PNEUMATIC TRASH COMPACTOR



Receiving Instructions

After delivery, remove the packaging from the product. Inspect the product closely to determine whether it sustained damage during transport. If damage is discovered, record a complete description of it on the bill of lading. If the product is undamaged, discard the packaging.

NOTE: The end-user is solely responsible for confirming that product design, use, and maintenance comply with laws, regulations, codes, and mandatory standards applied where the product is used.

Technical Service & Replacement Parts

For answers to questions not addressed in these instructions and to order replacement parts, labels, and accessories, call our Technical Service and Parts Department at (260) 665-7586. The department can also be contacted online at <https://www.vestil.com/page-parts-request.php>.

Electronic copies of Instruction Manuals

Additional copies of this instruction manual may be downloaded from <https://www.vestil.com/page-manuals.php>.

Table of Contents		Page
Specifications.....		2
Signal Words.....		3
Safety Instructions.....		3
Pneumatic Circuit Diagram.....		4
Exploded View and Bill of Materials.....		5 - 6
Operating the Compactor.....		7
Record of Satisfactory Condition.....		7
Inspections & Maintenance.....		7 - 8
Labeling Diagram.....		8
Limited Warranty.....		9


SPECIFICATIONS (22-007-021)

Specifications for MTC-series compactors are provided on Vestil's website. To access the appropriate specifications document, navigate to this webpage: <https://www.vestil.com/product.php?FID=1500>. Click the "Specifications" tab. Scroll the page to the entry for the model you purchased, and click the button in the PDF column that looks like a pencil inside a blue box. A PDF file will open. This file is the specifications document. Print a copy of the document and keep it with your copy of this manual. The following is an exemplar specifications document for model MTC-PNU-55.

HYDRAULIC TRASH COMPACTOR - MTC-PNU-55

APPROX WEIGHT: 367.23 lbs.
DOES NOT INCLUDE WEIGHT OF POWER OR PACKAGING!!!


*** ANY ADDITIONS, DELETIONS, OR OMISSIONS MUST BE CORRECTED ON THIS DRAWING AS THIS DRAWING WILL BE CONSIDERED ALL INCLUSIVE ***
ALL GRAPHICS PROVIDED ARE FOR REFERENCE ONLY. IF CERTAIN DIMENSIONS ARE CRITICAL PLEASE VERIFY THOSE DIMENSIONS WITH YOUR SALESPERSON



STANDARD FEATURES

MODEL NUMBER IS MTC-PNU-55
OVERALL WIDTH: 31 15/16"
USABLE WIDTH: 24 7/16"
OVERALL LENGTH: 32 1/16"
OVERALL HEIGHT: 91 3/16"
FULL STROKE COMPACTED HEIGHT IS 6 1/2"
FORK POCKET OPENING: 7 1/2" X 1 5/8"
USE WITH STEEL 55 GAL DRUMS
9000 LBS COMPACTING FORCE
POWER UNIT REQUIRES 90 PSI AND 15 CFM
MANUAL DIRECTIONAL CONTROL VALVE
DURABLE LIQUID PAINT BLUE FINISH

SPECIAL FEATURES NONE



**DOOR SHOWN
OPEN FOR REFERENCE**

DIMENSION TOLERANCE $\pm 1/4"$

APPROVAL	I, THE UNDERSIGNED, AGREE THAT THE PRODUCT AS REPRESENTED SATISFIES DESIGN AND DIMENSION REQUIREMENTS. I ALSO ACKNOWLEDGE MY DUTY TO CONFIRM PRODUCT AND INSTALLATION COMPLIANCE WITH ALL APPLICABLE FEDERAL, STATE AND LOCAL REGULATIONS AND STANDARDS.	
	UNITS REQUIRING APPROVAL DRAWINGS OR MODIFIED ARE NON-RETURNABLE	
	[] As drawn [] As marked	
	Signed: _____	Date: _____
	Printed Name: _____	
	LEAD TIME WILL START UPON RECEIPT OF SIGNED APPROVAL DRAWING	
DISTRIBUTOR'S NAME:	P.O.# X	
VESTIL MANUFACTURING		W.O.# X
DRAWN BY: CRH	DATE: 1/31/2020	SALES: X
REFERENCE: X	SCALE: 1:18	FILE NAME:
QUOTED LEAD TIME: X	QUOTE # X	22-007-021

SIGNAL WORDS

This manual uses SIGNAL WORDS to indicate the likelihood of personal injuries, as well as the probable seriousness of those injuries, if the product is misused in the ways described. Other signal words call attention to uses of the product likely cause property damage. The following are signal words used in this manual and their definitions.

 DANGER	Identifies a hazardous situation which, if not avoided, WILL result in DEATH or SERIOUS INJURY . Use of this signal word is limited to the most extreme situations.
 WARNING	Identifies a hazardous situation which, if not avoided, COULD result in DEATH or SERIOUS INJURY .
 CAUTION	Indicates a hazardous situation which, if not avoided, COULD result in MINOR or MODERATE injury.
NOTICE	Identifies practices likely to result in product/property damage, such as operation that might damage the product.

SAFETY INSTRUCTIONS



Vestil strives to identify all hazards associated with the use of our products. However, material handling is dangerous and no manual can address every risk. The most effective way to avoid injury is for the end-user to exercise sound judgment whenever using this product.

WARNING


Improper or careless operation might result in serious personal injuries or death.

- Read and understand the entire manual before installing, assembling, using, or servicing the product.
- Moving parts create pinch point and crushing hazards. Avoid contact with the cylinder and the platen whenever the cylinder is extending or retracting. Keep clear of all moving parts during operation.
- Do not operate the machine unless the pneumatic roller arm valve functions properly. The cylinder/ram should not extend or retract unless the guard is down. Do not disable the pneumatic roller arm valve.
- Do not stand in front of the barrel while operating the compactor. Only operate the compactor from behind the compactor (side opposite the guard).
- Do not use the compactor if it is damaged or makes unusual noises during operation.
- Do not compact materials inside a weakened or damaged drum. For example, do not compact materials inside a drum with a rusty bottom or side wall.
- Do not change the pressure relief valve setting! In particular, do not increase the setting.
- Do not inspect or maintain the compactor until it is disconnected from the air supply.
- This device utilizes pressurized air. Never apply pressurized air to the skin. Do not direct pressurized air at yourself or another person.
- Do not start the flow of pressurized air until the air supply hose is securely attached to the quick attach coupler.
- Always wear proper personal protective equipment (PPE) when operating this device.
- Always wear proper protective clothing. Normal work clothing does not provide sufficient protection against pressurized air.
- Do not modify the product in any way without first obtaining approval from the manufacturer. Unapproved modifications automatically void the LIMITED WARRANTY (p. 9) and might make the compactor unsafe to use.
- DO NOT use this device unless every label and tag is in place, undamaged, and easily readable from a reasonable distance. See LABELING DIAGRAM on p. 8.


PNEUMATIC CIRCUIT DIAGRAM (22-150-001)



1: 99-022-025



2: 99-163-007



3: 99-138-017

Item	Part no.	Description	Qty.
1	99-022-025	ACTUATOR,PNEUMATIC, N.C. SELECTOR SWITCH	1
2	99-163-007	VALVE, PNEUMATIC,N.C.ROLLER ARM	1
3	99-138-017	VALVE, PNEUMATIC, AIR PILOT OPERATED	1
4	99-162-004	PUMP, AIR/HYDRAULIC, 3 POS	1
5	99-021-069	CYLINDER, HYDRAULIC, Ø2" x 36", PISTON STYLE, FLANGE MOUNT	1

This technical drawing is an exploded view of a mechanical assembly, showing 27 numbered components and their relative positions. The main structure consists of a base (1) supporting a vertical column (19). A motor (7) is mounted on the side of the column. A horizontal arm (10) is attached to the column, and a pulley (9) is mounted on its end. A belt (11) is shown around the pulley. A motor (8) is mounted on the side of the main body. A horizontal arm (14) is attached to the motor. A pulley (15) is mounted on the end of the arm. A belt (13) is shown around the pulley. A motor (16) is mounted on the side of the main body. A horizontal arm (18) is attached to the motor. A pulley (17) is mounted on the end of the arm. A belt (20) is shown around the pulley. A motor (21) is mounted on the side of the main body. A horizontal arm (23) is attached to the motor. A pulley (25) is mounted on the end of the arm. A belt (26) is shown around the pulley. A motor (27) is mounted on the side of the main body. A horizontal arm (24) is attached to the motor. A pulley (2) is mounted on the end of the arm. A belt (3) is shown around the pulley. A motor (4) is mounted on the side of the main body. A horizontal arm (5) is attached to the motor. A pulley (6) is mounted on the end of the arm. A belt (7) is shown around the pulley. A motor (8) is mounted on the side of the main body. A horizontal arm (9) is attached to the motor. A pulley (10) is mounted on the end of the arm. A belt (11) is shown around the pulley. A motor (12) is mounted on the side of the main body. A horizontal arm (13) is attached to the motor. A pulley (14) is mounted on the end of the arm. A belt (15) is shown around the pulley. A motor (16) is mounted on the side of the main body. A horizontal arm (17) is attached to the motor. A pulley (18) is mounted on the end of the arm. A belt (19) is shown around the pulley. A motor (20) is mounted on the side of the main body. A horizontal arm (21) is attached to the motor. A pulley (22) is mounted on the end of the arm. A belt (23) is shown around the pulley. A motor (24) is mounted on the side of the main body. A horizontal arm (25) is attached to the motor. A pulley (26) is mounted on the end of the arm. A belt (27) is shown around the pulley.


BILL OF MATERIALS (22-006-021)

Item	Part no.	Description	Qty.
1	22-514-056	SUB-ASSEMBLY, FRAME	1
2	22-514-059	WELDMENT, FRAME, COMPACT PLATE	1
3	99-145-015	SPEC HARDWARE, SHOCK, TENSION	1
4	33006	FLAT WASHER,ZINC PLATED,USS, Ø5/16"	2
5	37026	JAM NYLOCK INSERT LOCK NUT, Ø 3/8 - 16 UNC, Z PLATED, GRADE 2	2
6	11107	HEX BOLT, GRADE A, ZINC FINISH, 3/8"-16 x 1-1/4"	2
7	99-162-004	PUMP, AIR/HYDRAULIC, 3 POS	1
8	99-529-150-002	SUB-ASSEMBLY, CONTROL BOX, 4" X 4" X 3"	1
*9	99-138-017	VALVE, PNEUMATIC, AIR PILOT OPERATED	1
10	23261	SHCS, 5/16-18 x 2" LONG	2
11	33620	LOCK WASHER, MEDIUM SPLIT, Ø5/16"	2
12	36104	HEX NUT, GRADE A, ZINC PLATED, 5/16-18	2
13	33618	MEDIUM SPLIT LOCK WASHER, Ø1/4"	4
14	11003	HEX BOLT, GRADE A, ZINC PLATED, 1/4-20 X 3/4"	4
15	36102	HEX NUT, GRADE A, ZINC PLATED, 1/4-20	4
16	99-163-007	VALVE, PNEUMATIC,N.C.ROLLER ARM	1
17	27327	SLOTTED ROUND HEAD MACHINE SCREW - #6 - 32 x 1	2
18	36020	MACHINE SCREW NUT, GRADE 2, #6-32	2
19	99-021-069	CYLINDER, HYDRAULIC, Ø2" x 36", PISTON STYLE, FLANGE MOUNT	1
20	37018	NYLON LOCK NUT,GRADE 2, ZINC FINISH,1/4"-20	1
21	22805	ELEVATOR BOLT, GRADE A, LIMIT SWITCH	1
22	11311	HEX BOLT, GRADE 2, ZINC FINISH, 5/8"-11 x 2"	4
23	36314	5/8"-11 UNC GR. 5 HEX NUT Z PLATED	4
24	11319	BOLT, Ø5/8-11 UNC x 4" LG	1
25	36114	HEX NUT Z-PLATED, GRADE A, Ø5/8 - 11 UNC	1
26	33630	5/8" ZINC FINISH MEDIUM SPLIT LOCK WASHER	1
27	22-516-010	WELDMENT, BRACKET, BACK STOP	2

OPERATING THE COMPACTOR


Apply the following steps to operate the compactor:

- 1) Grasp the handle and raise the guard.
- 2) Place a 55gal. barrel on the base.
- 3) Center the barrel beneath the platen.
- 4) Lower the guard. The compactor will not operate unless the guard is down.
- 5) Connect factory air to the quick-attach adaptor. Air pressure must be at least 80PSI (15CFM).
- 6) Turn the power toggle switch ON.
- 7) Stand behind the compactor (opposite the guard). Turn the compactor direction control lever counterclockwise to the DOWN position. The cylinder/ram extends. The platen compresses the contents of the barrel. When the cylinder achieves maximum extension, barrel contents are fully compacted.
- 8) Retract the cylinder by turning the direction control lever clockwise to the UP position.
- 9) Fully retract the cylinder/ram. Then, turn the power toggle switch OFF.
- 10) Raise the guard. Remove the barrel.
- 11) Lower the guard
- 12) Disconnect factory air.



Platen compacts drum contents


Air pilot operated valve mounted on pump



Pump

Air pilot operated valve

Control box with power toggle switch (shown OFF)



Roller arm valve

Quick attach adaptor

Platen

RECORD OF SATISFACTORY CONDITION

Before using the compactor for the first time, make a record of its appearance and operation. Thoroughly photograph the unit. Include close-range photographs of each label applied to the unit, the pump (7), the control box (8), the air pilot operated valve (9), the cylinder (21), and the roller arm valve (18). Cycle the compactor by following the [OPERATING THE COMPACTOR](#) instructions. Watch the cylinder and listen to the pump as the ram cycles. Record your observations about the sound of the motor and the movement of the ram. Collect all photographs and writings into a single file. This file is a record of the unit in satisfactory condition.

INSPECTIONS & MAINTENANCE

Disconnect the compactor from factory air and inspect it as instructed. Compare the results of each inspection with the [RECORD OF SATISFACTORY CONDITION](#) to determine whether the unit is in satisfactory condition. DO NOT use the compactor unless it is in satisfactory condition. Only use manufacturer-approved replacement parts to restore the unit to satisfactory condition. **DON'T GUESS! If you have any questions about the condition of your unit, contact the [TECHNICAL SERVICE](#) department.** The phone number is provided on the cover page of this manual. Never make temporary repairs of damaged or missing parts. Purely cosmetic changes, such as chipped paint, are not changes from satisfactory condition. However, touchup paint should be applied to all areas where the finish is damaged as soon as the damage occurs because exposed metal rusts. Left unaddressed, rusting could compromise the soundness of the metal and create a safety hazard.

At least once per month (once per week whenever the unit is used more than 5 times per week):

1. Examine the pneumatic system. Look for damaged hoses or fittings. In particular, look for kinks, punctures, tears, or other damage causing leaks.

2. Inspect the cylinder/ram. Operate the compactor through a full cycle by applying the [OPERATING THE COMPACTOR](#) procedure. Listen for unusual noises and watch for cylinder binding during the cycle. Check the cylinder to make sure that it is not bent, cracked, or otherwise damaged.
3. Make sure that labels are in place, undamaged, and easily readable. See [LABELING DIAGRAM](#) on p. 8.
4. Inspect the platen. Look for cracks, damaged welds, warps, etc. The platen must be securely fastened to the end of the cylinder. Examine all fasteners (pins, bolts, washers, nuts) for damage, corrosion, and rust.
5. Thoroughly examine the frame (base, fork pockets, and vertical supports) for cracks, rust, and corrosion. Clean the surfaces as needed. Keep the unit clean and dry.
6. Inspect the guard and the roller arm valve. Lift the guard. Make sure that the tension shock holds the guard in the raised position. Connect the unit to the air supply. Turn power on and turn the control lever to the ON position. The cylinder should not move while the guard is raised. Lower the guard. Confirm that the cylinder operates while the guard is lowered. Turn power off and disconnect the air supply.
7. Repair areas where the finish has been damaged. Use steel wool or a steel bristle brush and a slightly dampened cloth to remove rust. Apply touchup paint to the affected areas once they are dry.

LABELING DIAGRAM

Label content and location are subject to change so your product might not be labeled exactly as shown. Compare this diagram to the [RECORD OF SATISFACTORY CONDITION](#). Replace all labels that are damaged, missing, or not easily readable (e.g. faded). Order replacement labels by contacting the [TECHNICAL SERVICE AND REPLACEMENT PARTS DEPARTMENT](#) online at http://www.vestilmfg.com/parts_info.htm. Alternatively, you may request replacement parts and/or service by calling (260) 665-7586 and asking the operator to connect you to the Parts Department.

A: Label 1116



B: Label 220




C: Label 1114



D: Label 1115



E: Label 1117




F: Label 208



G: Label 1112

MODEL / MODELO / MODÈLE	_____
WEIGHT / PESO / MASSE	_____
SERIAL / SERIE / SÉRIE	_____



LIMITED WARRANTY

Vestil Manufacturing Company ("Vestil") warrants this product to be free of defects in material and workmanship during the warranty period. Our warranty obligation is to provide a replacement for a defective, original part covered by the warranty after we receive a proper request from the Warrantee (you) for warranty service.

Who may request service?

Only a warrantee may request service. You are a warrantee if you purchased the product from Vestil or from an authorized distributor AND Vestil has been fully paid.

Definition of "original part"?

An original part is a part used to make the product as shipped to the Warrantee.

What is a "proper request"?

A request for warranty service is proper if Vestil receives: 1) a photocopy of the Customer Invoice that displays the shipping date; AND 2) a written request for warranty service including your name and phone number. Send requests by one of the following methods:

US Mail
Vestil Manufacturing Company
2999 North Wayne Street, PO Box 507
Angola, IN 46703

Fax
(260) 665-1339
Phone
(260) 665-7586

Email
info@vestil.com
Enter "Warranty service request"
in the subject field.

In the written request, list the parts believed to be defective and include the address where replacements should be delivered. After Vestil receives your request for warranty service, an authorized representative will contact you to determine whether your claim is covered by the warranty. Before providing warranty service, Vestil will require you to send the entire product, or just the defective part (or parts), to its facility in Angola, IN.

What is covered under the warranty?

The warranty covers defects in the following original, dynamic parts: motors, hydraulic pumps, motor controllers, and cylinders. It also covers defects in original parts that wear under normal usage conditions ("wearing parts"), such as bearings, hoses, wheels, seals, brushes, and batteries.

How long is the warranty period?

The warranty period for original dynamic components is 1 year. For wearing parts, the warranty period is 90 days. Both warranty periods begin on the date Vestil ships the product to the Warrantee. If the product was purchased from an authorized distributor, the periods begin when the distributor ships the product. Vestil may, at its sole discretion, extend a warranty period for products shipped from authorized distributors by up to 30 days to account for shipping time.

If a defective part is covered by the warranty, what will Vestil do to correct the problem?

Vestil will provide an appropriate replacement for any covered part. An authorized representative of Vestil will contact you to discuss your claim.

What is not covered by the warranty?

The Warrantee (you) is responsible for paying labor costs and freight costs to return the product to Vestil for warranty service.

Events that automatically void this Limited Warranty.

- Misuse;
- Negligent assembly, installation, operation or repair;
- Installation/use in corrosive environments;
- Inadequate or improper maintenance;
- Damage sustained during shipping;
- Collisions or other accidents that damage the product;
- Unauthorized modifications: Do not modify the product IN ANY WAY without first receiving written authorization from Vestil.

Do any other warranties apply to the product?

Vestil Manufacturing Co. makes no other express warranties. All implied warranties are disclaimed to the extent allowed by law. Any implied warranty not disclaimed is limited in scope to the terms of this Limited Warranty. Vestil makes no warranty or representation that this product complies with any state or local design, performance, or safety code or standard. Noncompliance with any such code or standard is not a defect in material or workmanship.

