


PMM-3000-15



OPERATION, MAINTENANCE & PARTS MANUAL

TABLE OF CONTENTS

BASIC OPERATION

Introduction-----	1
Table of Contents-----	2
Warning-----	3
Keyed Switch-----	3
Variable Speed Control-----	3
Forward & Reverse-----	3
Hydraulic Switches-----	3
Brake Control-----	3
Standard Braking-----	3
Charging System-----	3
Steering-----	4
Hydraulic Lift-----	4
Hour Meter-----	4
Options-----	4
Safety Recommendation-----	4

GENERAL MAINTENANCE

Motors-----	5
Grease Fittings-----	5
Batteries-----	5
Hydraulic Fluid Level-----	5
Chains-----	5
Tires-----	5

REPLACING PARTS

Recommendations-----	5
Motor-----	6
Belts-----	6
Tires-----	6
Chains-----	7
Differential-----	7
Hydraulic Pump-----	7
Hydraulic Cylinders-----	7

PARTS BREAKDOWNS

WIRING DIAGRAMS

BASIC OPERATION

WARNING

Your Powermover was designed to move heavy objects and loads on nearly level surfaces.

Do not operate on slopes.

KEYED SWITCH

Your Powermover requires a key to turn the ignition switch on. Be sure to turn the key to the off position when your Powermover is not in use.

VARIABLE SPEED CONTROL

The speed control is operated with the right index finger and has a one second delay built into it. When you pull the speed control lever you will hear a click and experience a short delay before the Powermover begins to move. Do not pull the speed control lever to its maximum position until you get the feel of how the Powermover accelerates. The procedure should be slow at first and then faster as you become more experienced. **Caution: Before pulling the speed control lever be sure the forward/reverse switch is in the proper position, for the desired direction you want to go.**

FORWARD/REVERSE SWITCH

This is a simple rocker type switch and can be operated by using your right thumb. **Caution: Make sure you have selected the desired direction on the switch before activating the switch.**

HYDRAULIC SWITCH

Your Powermover is equipped with a hydraulic lift. There is a switch on the handle to control the up/down motion of the mast. Pull back on the switch to raise the mast and push forward on the switch to lower the mast. Note: The switch is spring loaded and requires you to hold the switch on until the mast reaches the desired height.

BRAKE CONTROL (OPTIONAL)

If your Powermover has the seven way connector mounted on the top front of the Powermover, then it has a push button switch on the handle to activate the receptacle. This button is used to activate the trailer brakes if they are plugged into the standard seven way connector allowing the trailer brakes to stop the load.

MAGNETIC BRAKING 2 HP CONTINUOUS DUTY MOTOR

The continuous duty motor, with its standard hookup, will stop the Powermover when the speed control is released after a three second delay.

CHARGING SYSTEM

Your Powermover is equipped with a built-in-charging system. It requires a standard three prong extension cord to use the battery charger. The male end, plugs in to a standard 120 volt outlet, and the female end, plugs into the receptacle located on the right of your Powermover. When your Powermover is not in use you should leave the charger plugged in. When you first plug your charger in you will see a red light come on. This is normal. When the batteries are near a full charge you will see a red and a green light. When the red light goes out and only the green light is on you have reached a full charge. It will not damage the batteries to leave the charger plugged in. You also have a battery level indicator

that will show the amount of charge left in your battery. It is located on the handle of your Power mover.

SAFETY SWITCH

The reversing safety switch is located on top of the handle and is designed to activate if you are backing up and it hits your belly. When the switch hits your belly it will depress the switch, which immediately reverses the motor. It is not possible to go backwards when the switch has been activated until you reset the switch. You reset the switch by turning it clockwise. You will hear a click and see the switch pop out to its normal set position. You will now be able to go in reverse.

STEERING

Your Powermover is equipped with a steering handle that directly turns the rear wheel of the Powermover when pushed to the right or left. **CAUTION: WHEN FIRST LEARNING TO OPERATE THE POWERMOVER SLOW AND EASY IS THE BEST POLICY FOR BOTH THE SPEED CONTROL AND THE STEERING CONTROL. USE SLOW SPEED WHEN MAKING TURNS.**

HYDRAULIC LIFT

The hydraulic lift is designed to provide additional traction when moving heavy objects by transferring some of the weight from the object being moved to the front drive wheels of the Powermover. This transfer of weight is essential to move many of the heavier objects

HOUR METER

The hour meter is standard equipment on every Powermover as of June 1, 2001. We suggest you keep a log book so you know the proper time to service your Powermover. The hour meter is located in the handle.

OPTIONS

WEIGHT KIT

Sometimes it is necessary to add weight to move certain loads, especially on non-hydraulic lift models. A variety of weights are available to assist where needed.

NON MARKING TIRES

Gray non marking tires are available for the Powermover.

ATTACHMENTS

Many jobs require some type of special attachment. We custom make whatever is necessary to do the job. The following standard brackets are available. J-type hooks, pintle hooks, hitch balls, hitch pins, o-rings and saddles. The attachments are adjustable to fit almost any need.

SAFETY RECOMMENDATION:

IT IS RECOMMENDED THAT WHEN LIFTING A LOAD WITH THE HYDRAULIC LIFT THAT YOU ONLY LIFT IT HIGH ENOUGH TO CLEAR THE GROUND SURFACE AND THEN MOVE THE LOAD. SHOULD YOU FEEL UNCOMFORTABLE WHILE MOVING THE LOAD YOU CAN QUICKLY LOWER IT TO THE GROUND.

GENERAL MAINTENANCE

2 HP MOTOR CONTINUOUS DUTY: This powerful motor is designed for continuous use. It is a permanent magnet motor and acts as a brake when the speed control is released. Its bearings are factory sealed and require no maintenance; the brushes should be checked every 500 hours of operation.

GREASE FITTINGS

Shafts (grease every 1000 hours of operation)

- 1) 1 at the differential shaft
- 2) 1 at the rear steering wheel

BATTERIES

Check the electrolyte level in each of the battery cells to be sure they are ½" above the top of the lead plates. **Caution: Never let the electrolyte drop below the top of the lead plates and never smoke or have an open flame near the batteries. A spark or open flame could cause an explosion causing injury.**

HYDRAULIC FLUID LEVELS

Check the hydraulic reservoir at least every 150 hours. If it is low bring the level back up to the full mark. Also check the hose and fittings at the same time for any fluid leaks.

CHAINS

Lubricate the chains once every year with motorcycle chain type grease.

TIRES

Your Powermover may have foam filled tires. This allows for the tires to carry more weight, adds more weight and prevents flat tires from ever occurring.

REPLACING PARTS

RECOMMENDATION

It is recommended that only mechanics service or replace parts on your Powermover.

Ultra-Fab stocks any and all parts necessary to keep your Powermover in good operating condition

Allowing for the best possible service. Many of the parts are self explanatory and very easy to replace. The parts breakdown will show you where these parts go but does not explain how to change because it is obvious.

NOTE: SHOULD YOU HAVE ANY QUESTIONS CALL ULTRA-FAB AT 800-860-7571

MOTOR 2HP CONTINUOUS DUTY

STEP 1) Open the door to battery compartment and disconnect the negative leads on the battery terminal (2 places) This eliminates all power to the motor and the handle.

STEP 2) Remove the top cover by removing the four screws. Disconnect the two wires from the motor terminals.

STEP 3) Loosen and remove the four bolts on the motor mount plate and lift the motor up and out of its location. (The belt will come off the drive sheave as you remove the motor and mount plate).

STEP 4) To reinstall reverse steps 1-3. The mounting plate has adjustments from side to side and well as up and down. Install the motor in a way that the belt tracks true from pulley to pulley, this is achieved with the side to side adjustments, and then adjust the belt tension with the up and down adjustments.

(Hint: the top of the motor mount plate should be parallel with the top of the chase frame.)

COG TYPE BELT (ON ALL MODELS BUILT AFTER (2/1/05) (Shaft # 1)

A cog type belt is used to drive the power from the motor to a large cog type sheave on the main shaft. You can replace the belt with out disassembling the unit. To replace the cog belt follow these steps.

STEP 1) Follow the first 2 steps above on replacing the motor.

Step 2) Release belt tension on the motor. To achieve this loosen the 4 bolts holding the motor mount plate. Allow the motor to slide down the elongated slots, this will loosen the belt.

Step 3) Inside the housing locate the bearing block next to the cog pulley, you will see two (2) set screws, loosen or back off the set screws, DO NOT remove them.

Step 4) On the outside of the housing (belt side) , remove the access plate (4 5/16 bolts) the bearing block will come off with it.

Step 5) With the access plate removed you can remove and install a belt with out dismantling the gears and pulleys.

Step 6) Replace the access plate and tighten up the set screws on the inside bearing block.

Step 7) Adjust the tension on the belt by lifting the motor (pulling it up the elongated slots) this will tighten the belt, secure it to the frame by tightening the 4 bolts.

Step 8) Replace covers

Step 9) Reconnect batteries

FRONT DRIVE TIRES

To change a tire is just like a car. Remove the lug nuts and the tire and wheel will pull straight out and off.

REAR STEERING TIRE

This tire is mounted between a yolk with a single large bolt held in place with a nut. You must hold one end of the bolt while you loosen the nut.

CHAINS

Adjustment of the chains is accomplished by loosening the bolts securing the bearing block to the frame, and then adjusting the tightening screw. This will push the bearing block and tighten the chain and keep it from moving when you are pulling a heavy load. Once the chains are tensioned lock down the bearing blocks, by securing the bolts. To remove or replace the chain, you must first identify the master link by rotating the chain until you see the master link. Then use needle nose pliers to remove the keeper and pull the chain apart. You can now reverse the steps and put the master link back together.

DIFFERENTIAL (Shaft # 2)

The differential is installed in your Powermover to allow one wheel to stand still or go backwards while the other wheel goes forward during a turn. The differential is located in the front section of the drive assembly. To access it you will need to remove the Cog belt pulley shaft, and the hydraulic pump. This will give you access to the differential shaft.

Step 1) remove the hydraulic pump

Step 2) Remove the cog belt pulley shaft

Step 3) Remove the chains that go around the sprockets on the shaft. See "chains" above.

Step 4) Remove the 4 bolts that hold both the right and left flange bearings (2 each) and lift the differential out of the main body.

Step 5) Transfer the bearings, sprockets, spacers and lock collars to the new differential shaft making sure they are back in the same order as on the old shaft.

Step 6) Reverse steps 1-4 and make sure all bolts are tight.

HYDRAULIC PUMP

STEP 1) Remove cover top plate.

STEP 2) Disconnect hydraulic hoses (prepare for leakage of hydraulic fluid)

STEP 3) Disconnect 12 volt wires.

STEP 4) Remove the 2 bolts holding the pump to the main chassis. Easily accessed on the right side of the chassis.

STEP 5) Install new pump and reverse steps 1-4. Then check the hydraulic fluid level in the reservoir to make sure it is at the proper level. There is a line showing where the level should be.

STEP 6) It will be necessary to operate the cylinder all the way up and all the way down to purge the air from the lines. NOTE: You may need to do this procedure more than once to clear the air from the lines.

HYDRAULIC CYLINDER

STEP 1) Remove the pin that holds the shaft of the hydraulic cylinder to the inner mast.

STEP 2) Remove the inner mast by pulling it straight up and out of the outer mast.

STEP 3) Disconnect the upper and lower hoses.


STEP 4) Remove cylinder and replace with new one.

STEP 5) Reverse steps 1-4 and add the proper amount of hydraulic fluid to bring the level up to the full line.


STEP 6) It will be necessary to purge the lines of air. Do this by operating the cylinder to a full up and then down position. You may have to do this procedure more than once to get all the air from the lines.

MOTOR ASSEMBLY

NO.	QTY.	PART #	DESCRIPTION
1	1	41-013659	PLATE-MOTOR MOUNT
2	1	41-000688	MOTOR-2 HP. (CONT.)
3	1	41-050113	SHEAVE-15T BELT
4	1	41-000544	KEY-3/16 X 3/4"




chassis



NO.	QTY.	PART #	DESCRIPTION
1	1	41-013566	FRAME-MAIN
2	1	41-013573	MAST-OUTER
3	2	SHAFT 3	SHAFT 3 (SEE BREAKDOWN)
4	1	SHAFT 2	SHAFT 2 (SEE BREAKDOWN)
5	1	SHAFT 1	SHAFT 1 (SEE BREAKDOWN)
6	1	MOTOR ASSEMBLY	MOTOR ASSEMBLY (SEE BREAKDOWN)
7	1	41-013554	HOUSING-FRONT WELDMENT
8	2	SHAFT 4	SHAFT 4 (SEE BREAKDOWN)
9	1	41-030090	BUSHING-1 1/4" ID.
10	1	41-020096	WASHER-2.5" X 1.25"
11	1	41-090120	BEARING
12	1	41-013572	YOKE-STEERING
13	1	41-210010	COLLAR-1 1/4" SPLIT
14	1	41-000293	KEY-1/4 X 3/4"
15	1	41-013633	PLATE-ADAPTER
16	1	41-013641	PLATE-HANDLE MOUNTING
17	2	41-013607	PLATE-STEERING ADJ.
18	2	41-013592	SPACER-REAR TIRE
19	1	41-500112	TIRE-4.8/4.0-8
20	2	41-500101	TIRE-18"
21	1	41-001090	LOCATOR-CYLINDER
22	1	LCYLINDER	CYLINDER-LARGE
23	2	41-013606	SPACER-CYLINDER
24	1	41-013574	MAST-INNER
25	12	17-113320	WASHER-5/8" FLAT
26	4	41-141013	ROLLER-MAST
27	1	41-013602	STOP-CYLINDER END
28	1	41-141026	5TH WHEEL HITCH
29	1	41-013648	FENDER-RIGHT
30	1	41-013647	FENDER-LEFT


NOTE: NON MARKING TIRES # 19 USE 41-500114
#20 USE 41-500113

HANDLE



NO.	QTY.	PART NO.	DESCRIPTION
1	1	41-010005	HANDLE-LOWER
2	3	41-940601	TERMINAL STRIP
3	1	41-940582	BREAKER-40 AMP
4	1	41-940002	SWITCH-ROCKER
5	1	41-010008	HANDLE-LEFT
6	1	41-010009	HANDLE-RIGHT
7	1	41-940538	SWITCH-KEY
8	1	41-141003	THROTTLE-PB6
9	1	41-141038	METER-HOUR
10	1	41-141011	INDICATOR-BATTERY
11	1	41-940580	SOCKET-12 PIN
12	1	41-612416	HANDLE
13	2	41-900239	GRIP-HANDLE
14	1	41-013509	BRACKET-RELAY
15	1	41-940016	RELAY-TIMER
16	1	41-940017	RESISTOR
17	1	41-013508	COVER-RELAY
18	1	41-013598	COVER-CHARGER INLET
19	1	17-101011	SWITCH-12 VOLT
20	4	17-143097	BOOT SNAP SEAL
21	1	41-940006	SWITCH-ON/OFF
22	1	41-940007	SWITCH-OFF/ON
23	1	41-940015	SWITCH-ON/OFF
24	1	41-001016	BOX-EMERGENCY
25	1	41-001017	COVER-EMERGENCY
26	1	41-940005	SWITCH-EMERGENCY REV.


CHASSIS



NO.	QTY.	PART #	DESCRIPTION
1	1	41-013566	FRAME-MAIN
2	1	PUMP	PUMP
3	2	41-940004	VALVE-HYD.
4	1	41-001008	MAIN-FRONT LIFT
5	1	41-013554	HOUSING-FRONT WELDMENT
6	1	41-013668	PLATE-TOP COVER
7	4	41-001001	BATTERY-12 VOLT
8	6	41-013521	CLIP-BATTERY
9	1	41-013586	PANEL-REAR
10	1	41-013636	SHIM-DOOR
11	1	41-013583	SIDE-RIGHT
12	1	41-940488	COVER-INLET
13	1	41-141000	SOLENOID-DC88
14	1	41-013584	SIDE-LEFT
15	1	41-013589	PANEL-FRONT
16	1	41-013587	PANEL-TOP BACK
17	1	41-013585	PLATE-BATTERY CHARGER
18	2	41-940500	CHARGER-BATTERY
19	1	41-141039	CONTROLLER-MOTOR
20	2	41-940601	TERMINAL STRIP
21	1	41-940442	CONNECTOR-FEMALE 7 WAY
22	1	41-013657	DOOR-LEFT SIDE
23	2	41-141018	BRACKET-STRUT
24	1	41-013588	DOOR-TOP
25	1	41-900023	KNOB
26	1	CYLINDER	CYLINDER-7"
27	1	41-013547	ADAPTER-CYLINDER
28	1	41-001005	PLATE-ROLLER
29	4	41-141010	CAM-FOLLOWER
30	4	41-010044	SPACER-LIFT
31	4	41-020060	NUT-7/8-14
32	1	41-001006	BRACKET-HITCH B ALL
33	1	41-290157	BALL-HITCH
34	1	41-141016	STRUT-DOOR


SHAFT 1

NO.	QTY.	PART #	DESCRIPTION
1	1	41-070506	SHAFT-SPROCKET
2	2	41-090115	BEARING-SIDE
3	1	41-030071	WASHER-1.5" X 1" X 14GA.
4	1	41-030040	WASHER-1.5" X 1" X 18GA.
5	1	41-050114	HUB-SHEAVE
6	1	41-050112	SHEAVE-84T BELT
7	1	41-210005	COLLAR-1" SPLIT
8	7	41-030072	WASHER-1.5" X 1" X 10GA.
9	1	41-000292	KEY-1/4 X 1 1/8"
10	1	41-000293	KEY-1/4 X 3/4"
11	1	41-210003	COLLAR-1" FULL SPLIT
12	1	41-040152	SPROCKET-40BS15 X 1"



**DIFFERENTIAL SHAFT
(SHAFT 2)**

NO.	QTY.	PART #	DESCRIPTION
1	1	41-001379	DIFFERENTIAL-H.D.
2	2	41-090115	BEARING-SIDE
3	2	41-040177	SPROCKET-40BS20 X 1"
4	2	41-210005	COLLAR-1" SPLIT
5	2	41-000293	KEY-1/4 X 3/4"
6	1	41-040170	SPROCKET-40A48 W/2.1/8 BORE
7	2	41-010044	SPACER-LIFT
8	2	41-030071	WASHER-1.5" X 1" X 14GA.




4	1	41-040175	SPROCKET-50B3
5	1	41-010062	SPACER-1.06 X 1
6	1	41-210005	COLLAR-1" SPLIT
7	1	41-000292	KEY-1/4 X 1 1/8"
8	1	41-000293	KEY-1/4 X 3/4"
9	3	41-030072	WASHER-1.5" X 1

REV: 05/05


REV: 05/05

AXLE SHAFT (SHAFT #4)


NO.	QTY.	PART #	DESCRIPTION
1	1	41-070625	STUBAXLE
2	2	41-090118	BEARING-1 1/2" SIDE
3	1	41-040168	SPROCKET-50BS32 X 1.5"
4	1	41-000295	KEY-3/8 X 1 1/8"
5	1	41-210004	COLLAR-1 1/2" SPLIT
6	1	41-030051	WASHER-2.25" X 1.5" X 10GA.
7	1	41-030042	WASHER-2.25" X 1.5" X 14GA.



Handle Wiring Diagram



CHASSIS WIRING



CHASSIS WIRING

